#### Thule ClampOn

# Adapter kit for various factory fitted roof racks.

Clamp-Ons are adapter kits allowing certain Thule ski carriers to fit directly to factory-fitted and fixed-installation roof racks. Clamp-Ons are available in a variety of sizes and shapes. The following Thule ski carriers can be used together with Clamp-Ons: Snowpro SA 740, 726, 727, 745 and 746.

If you only want to transport skis on your roof rack, this is the perfect solution.



ClampOn



MAZDA

	ClampOn
CHRYSLER	
Voyager 96 to 7/01	C34
Grand Voyager 96 to 7/01	C34
Grand Voyager 8/01 on	C23

#### FORD

C27
C27
SAFM1

#### HONDA

CRV, 6/97 to 11/01	C25

# HOLDEN

Frontera 9/98 on	C36
Suburban 1/98 on	C29
Commodore Wagon 9/97 on	C31
(Factory Genuine Racks)	

# HYUNDAI

Santa Fe, 03/06 on	C31

### JEEP

 Sports Cherokee 4/94 to 7/99
 C25

 Grand Cherokee 7/96 to 6/99
 C26

 Grand Cherokee 7/99 on
 C34

Carneval 8/99 on	C34
Sorento 02 on	C36

C27

LEXUS	
RS350	

MPV 7/99 on	C27
Tribute 2/01 on	C27
NISSAN	
Pathfinder 1/02 on	C27
RENUALT	
Scenic 5/01 on	C36
SUBARU	
Forester up to 7/02,	
(Factory Genuine Racks)	C31
RHINO SPORTZ	SA888
(Delux fit as standard while	
snowpro need SA888)	
ROLA ROOF RACKS	C31

# \* New. If your car is not listed here, please use part number SA FM1.

<u>Fat Mouth Ski Attachment:</u> A universal ski clamp which attaches our DeLuxe and SnowPro ski arms to most types of factory fitted racks, including Rola & Rhino Sportz Racks. No need to purchase a new clamp set when you attach to different rack.

(SA FM1 can be used instead of any C-ClampOn)

